

# Boat instruments

## Tank senders / sensors

### Universal sender for fresh water, petrol/gasoline and diesel fuel

Universal tank sender for fresh water, petrol and diesel fuel (type SENSOR). Available in seven different lengths: 280, 320, 380, 480, 580, 680 or 780 mm. The VETUS universal tank sender indicates the difference in fluid level in steps of 2.5 cm. Just compare this with other systems which can only show three positions (full - about half full - empty).

#### Specifications

- Empty 300  $\Omega$
- Full 10  $\Omega$
- For 12 and 24 VDC

Each tube length consists of the maximum number of read contacts (electronic switches), instead of the bare minimum of three (full, half full, empty). As a result VETUS tank gauges display tank levels with maximum accuracy. The read contacts are sealed "fluid-tight".

Type	Length (mm)	Voltage (DC)
SENSOR280	280	12/24
SENSOR320	320	12/24
SENSOR380	380	12/24
SENSOR480	480	12/24
SENSOR580	580	12/24
SENSOR680	680	12/24
SENSOR780	780	12/24



**SENSOR**

### Tank level sensor

The tank level sensor measures the tank level of petrol, gasoline, diesel and fresh water tanks. Output: NMEA2000 signal.

#### Specifications

- 9-16V operating voltage
- IP67 rating

Type	Description	Length (mm)
CANNFLS28	Tank level sensor	280
CANNFLS32	Tank level sensor	320
CANNFLS38	Tank level sensor	380
CANNFLS48	Tank level sensor	480
CANNFLS58	Tank level sensor	580
CANNFLS68	Tank level sensor	680
CANNFLS78	Tank level sensor	780

**CANNFLS**



**NEW!**

### Waste water tank sensor type WWSENSOR A

#### Easy measurement

Simple to fit, reliable waste water tank sensor. Adjustable arm length ranging from 200 to 412 mm.

#### Specifications

- Empty 300  $\Omega$
- Full 0  $\Omega$
- For 12 and 24 VDC

Type	Description	Voltage (DC)
WWSENSOR A	Waste water sensor	12/24

**WWSENSOR A**

